

Getting Started



DROID X



Important Customer Information

Please be advised that many services and applications offered through this unique device are provided by various device, operating system, software and application developers (e.g. Google, Motorola, Microsoft, Palm, Research in Motion). If you use, link to or download such a service, or an application such as a non-Verizon Wireless location based GPS-type service, chat room, marketplace or social network from this device, you should carefully review the terms of such service or application. If you use any of these non-Verizon Wireless services or applications, personal information you submit may be read, collected, or used by the service or application provider and/or other users of those forums.


Verizon Wireless is not responsible for your use of those applications or information you choose to submit or share with others. Specific terms and conditions, terms of use, and privacy policies apply to those applications and services. Please review carefully any and all terms and conditions applicable to those applications and services including those related to any location-based services for any particular privacy policies, risks or waivers.

Your Verizon Wireless customer agreement terms and conditions and certain other specifically identified terms govern your use of any Verizon Wireless products and services.

Device Layout



Charge and Power On Your Phone



Remember to fully charge your battery before use.

To turn your phone on or off, press and hold the **Power Key**

Google Account Set-up

When you turn your phone on for the first time, you will be prompted to set up your existing Gmail™ account. If you don't have one, you can create one. **Touch the Android to begin.**



Now your Gmail, Google contacts, and Google calendar events will all be loaded to your phone automatically.

Use the area below to record your Google account information for future reference.

Username: _____@gmail.com

Password: _____

Touch Screen Tips

There are several touch motions recognized by the phone:

Touch – to select a menu item or open an application

Touch and hold – to grab an object that you want to move or open an option menu

Drag – to move an object or scroll slowly on a list or web page

Flick – to scroll quickly on a list or web page (touch the screen again to stop the scrolling action)

Double tap* – to zoom in/out on a web page or picture

Multi touch* – pinch or spread thumb and index finger to zoom out or in

* Works when viewing browser, map or pictures.

For More Help

On the phone:
Help Center app
To access the app from the home screen, touch: **Launcher icon** > **Help Center**

By phone:
Motorola's Android help line: **1-800-734-5870**

On the web:
www.motorola.com/mydroidx

To order a printed copy of the manufacturer's User Guide/Manual, please call **1-800-734-5870**. To download a copy, please visit support.vzw.com/phones.

Screen shots are simulated. Actual display may vary.
Instructions to perform the tasks highlighted in this product guide may change depending on the software version on your phone.

MOTOROLA and the Stylized M logo are registered in the US Patent and Trademark Office.
Google, the Google logo, Google Maps, Gmail, YouTube, Google Talk, Android, and Android Market are trademarks of Google, Inc.

Facebook is a registered trademark of Facebook, Inc.

DROID is a trademark of Lucasfilm Ltd. and its related companies. Used under license.
All other product and service names are the property of their respective owners.

©2010 Verizon Wireless. All Rights Reserved. verizonwireless.com

Notifications

Notifications let you know when an event has occurred that may require your attention such as voicemail, missed calls, text messages, etc.

To view your notifications, touch the status bar at the top of the screen and drag it down. Touch each notification to view the details.



Lock and Unlock Screen

Your display will go dark if untouched for a period of time. Press the **Power/Lock Key** or **Home Key** to wake it up again. This lock screen will appear.



Sleep Mode: From any screen you can put your display into sleep mode. Just press the **Power/Lock Key** . This will prevent false key presses as well as help you conserve battery life.

To unlock the screen, touch the unlock icon and drag it to the right.

Home Screen

Your home screen has 7 panels.
Press the **Home Key** to go to the home screen.

Personalize: Touch and hold any open area on your home screen to add shortcuts, widgets, folders or change wallpaper.

You can also resize some widgets. Just touch and hold the widget, then drag one of the corners to expand or contract it.

To remove an item from your home screen, touch and hold the item then drag it to a trash bin that will appear at the bottom of the screen.

To rearrange the items on your home screen, touch and hold each item then drag it to its new position.

NOTE: Your home screen may appear different depending on the software version on your phone.



Slide your finger to the right to see the left panels of your Home screen.

Slide your finger to the left to see the right panels of your Home screen.

Application Tray

From the home screen, touch the **Launcher icon** to open the Application Tray. Open an application simply by touching it.



Enjoy preloaded applications such as **Google Maps**, **Google Talk**, **YouTube™**, **Gallery**, **Skype Mobile™**, and **Visual Voicemail**.

Email Setup

Your phone will provide instant access to your Gmail, Google Contacts, and Google Calendar as soon as you set up your Google account during activation. Linking all of your other email addresses to your phone is quick and easy.

If you did not setup your Google account during initial set up, from the home screen, open the **Application Tray** by touching the Launcher icon, touch **Gmail** and follow the on screen instructions.

To set up other accounts follow the instructions below. See the Tips and Additional Information section for more information.

Many consumer email accounts can be set up following these steps. From the **Application Tray**, touch **My accounts** > **Add account**.

Calling & Contacts

To make a call:

1. From your home screen, touch the **Phone** icon.
 2. Touch **Dialer** and enter the phone number, then touch **Call**.
- OR**
- touch **Contacts** tab, touch the contact you want to call, then touch **Call**.



To pair and connect to a Bluetooth headset:

1. From your home screen, touch the **Menu Key**.
2. Touch **Settings**.
3. Touch **Wireless & networks**.
4. Touch **Bluetooth** to turn on Bluetooth power.
5. Touch **Bluetooth settings**.
6. Touch **Scan for devices** (make sure your headset is in pairing mode).
7. Touch on the device name that you want to pair with (if prompted to enter a passcode, enter 0000 or the code provided by the headset manufacturer).
8. Touch again on the device name to connect to it.

To set up voicemail:

1. From your home screen, touch the **Phone** icon.
2. Touch ***86** then **Call**.
3. Touch **Call** so you can enter numbers.
4. If you hear a system greeting, touch # to interrupt it, if applicable.
5. Follow the setup tutorial.
6. Create a password.
7. Record a voice signature and greeting for your Voice Mailbox.

NOTE: You can also use Visual Voicemail to retrieve your voice messages. The Voicemail icon is located in the Application Tray. Subscription rates apply.

Tips and Additional Information

- From your Inbox, you can select **Menu**, **Settings** and explore your options.

You can set how often you want the DROID X to check for new email (longer intervals can be used to extend battery life), your default email account, how you are notified of new email, and more.

- If an email account is unable to be configured, as an alternative it may be possible to access it via the Web Browser. Contact your email provider for additional information.

Enterprise Email Account Setup

DROID X by Motorola supports the capability to sync with Microsoft® Exchange. In order to connect your DROID X phone with your Exchange server, please contact your administrator.

For more information on how to set up your email, visit smartphones.verizonwireless.com. Click on the Smartphone Support tab and select your phone.

To add a new contact:

1. From your home screen, touch **Contacts**.
2. Touch the **Menu Key**.
3. Touch **Add contact**.
4. Continue to follow the on-screen prompts then touch **Done** when you are finished. (When filling out data fields, touch the field to bring up the touchpad so you can enter data. When you are done with a field, touch **Next**.)

Transferring contacts:

For existing Verizon Wireless customers that have used Back Up Assistant and would like to transfer their contacts from their phone to the DROID X, go to the Application Tray and touch **Backup Assistant**.

For other options to sync your contacts from your previous phone or PC to your Google contacts, (which will sync to your phone) check out Google's Sync Services at www.google.com/sync.

NOTE: When you set up your Gmail account and social network account(s) the contacts from those accounts will automatically be transferred to your phone.

Essential Accessories

Car Mount Phone Holder*

- Automatically triggers your favorite driver focused phone applications like music, Google Navigation™, or your favorite Android apps.

- Drive smarter by taking your calls hands-free.

HDMI Multimedia Station*

- Instantly turns phone into an HD multimedia experience, and doubles as a charger when used with included power supply.

- Brilliantly displays your captured photos and movies in HD, plays music with album art, displays weather and time, and can be used as an alarm clock – all when you dock your phone.

HDMI Cable*

Connect your phone directly to a compatible HD TV to experience captured pictures and video.

* Optional accessories available for purchase at Verizon Wireless locations.

HD Video



To take HD quality videos:

1. From your Application Tray, touch **Camcorder**.
2. Enhance the video quality by adjusting these setting options: **Scenes**, **Effects**, and **Light**.
3. Press the Camera Key (see Device Layout page) to start recording and press it again to stop.

To play your videos on a TV, monitor or projector over HDMI:

1. Switch the input mode of your display device to HDMI.
2. Connect your phone to your display device using an HDMI cable (Type D required; sold separately).
3. From your Application Tray, touch **Gallery** and select a video to play.

NOTE: You can only play DRM-free videos over HDMI. HD support is 720p.

Top 10 Tips and Features

1. Manage your battery life:

From your home screen, touch the **Menu Key** > **Settings** > **Battery Manager** > select a battery profile that suits your usage habits.

2. Watch YouTube™ videos in high resolution:

While a video is loading to play, touch **HQ** which is on the lower right corner of the screen.

3. Set up your phone on a Wi-Fi network:

From your home screen, touch the **Menu Key** > **Settings** > **Wireless & networks** > **Wi-Fi** (to turn on Wi-Fi) > **Wi-Fi settings** > select the Wi-Fi network that you wish to connect to > **Connect** > enter security code if applicable.

4. Use SWYPE for super-fast text entry:

At any text entry box, touch and hold the box > **Input method** > **SWYPE**

5. Use Media Share to share content with other devices or transfer files to or from your PC:

From the Application Tray, touch **Media Share** to launch. A USB cable may be required.

6. Use Skype Mobile on your phone:

From your Application Tray, touch **Skype Mobile** to launch. Calling minutes will be used.

Android Market

Tens of thousands of applications and games, many free, are available for download on Android Market.

NOTE: You will need to have your Google account set up before you can download apps from Android Market. To set up your Google account, touch **Gmail** in the Application Tray.

To download an application:

1. From your home screen, touch **Market**.
2. Browse for an application or game.
3. Complete the purchase process, if applicable. (You will need a credit card account to make a purchase. Paid applications can be returned for a full refund within 24 hours of purchase).
4. Touch **Install**.

NOTE: You will receive a notification when your application is fully downloaded. You can find your application in alphabetical order on the Application Tray.

To remove an application:

1. From your home screen, touch **Market**.
2. Touch **Menu Key**.
3. Touch **Downloads**.
4. Touch the application that you want to remove.
5. Touch **Uninstall**, then confirm by touching **OK**.

* If you receive an error message stating "Setup Could Not Finish" check with your mail provider to confirm incoming server settings and settings to access their outgoing server from other networks. Also see the Tips and Additional Information.