



motorola **W370**


**User's Guide**



# HELLOMOTO

---

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola W370 wireless phone.



Motorola, Inc.  
Consumer Advocacy Office  
1307 East Algonquin Road  
Schaumburg, IL 60196

[www.hellomoto.com](http://www.hellomoto.com)

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. 2006 All other product or service names are the property of their respective owners.

© Motorola, Inc. 2007.


**Caution:** Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

Manual Number: 6809512A76-A

# check it out!

---



**Note:** Your phone may not appear exactly as the phone image above.

# contents

---

<b>check it out!</b> . . . . .	<b>3</b>	text entry . . . . .	22	return a call . . . . .	32
<b>menu map</b> . . . . .	<b>6</b>	volume . . . . .	25	hold or mute a call . . . . .	32
<b>Use and Care</b> . . . . .	<b>8</b>	navigation key . . . . .	25	call waiting . . . . .	32
<b>essentials</b> . . . . .	<b>9</b>	handsfree speaker . . . . .	25	caller ID . . . . .	33
about this guide . . . . .	9	codes & passwords . . . . .	26	emergency calls . . . . .	33
SIM card . . . . .	10	check battery meter . . . . .	26	international calls . . . . .	34
battery . . . . .	10	<b>customize</b> . . . . .	<b>27</b>	1-touch dial . . . . .	34
turn it on & off . . . . .	12	ring style . . . . .	27	voicemail . . . . .	34
make a call . . . . .	12	time & date . . . . .	27	inserting special	
answer a call . . . . .	13	wallpaper . . . . .	28	characters into dialing	
your phone number . . . . .	13	screen saver . . . . .	29	sequences . . . . .	35
<b>main attractions</b> . . . . .	<b>14</b>	display appearance . . . . .	29	<b>other features</b> . . . . .	<b>37</b>
multimedia messages . . . . .	14	answer options . . . . .	29	advanced calling . . . . .	37
chatting . . . . .	16	optional handsfree		contacts . . . . .	39
<b>basics</b> . . . . .	<b>17</b>	operation . . . . .	30	messages . . . . .	42
display . . . . .	17	<b>calls</b> . . . . .	<b>31</b>	chat . . . . .	43
menus . . . . .	21	call history . . . . .	31	web browser (wap 2.0) . . . . .	43
		redial . . . . .	32	personalizing . . . . .	44

call times & costs . . . .	47	<b>service &amp; repairs . . . . .</b>	<b>53</b>	<b>California Perchlorate Label</b>	<b>70</b>
handsfree operation . .	48	<b>Specific Absorption Rate</b>		<b>Privacy and Data Security .</b>	<b>70</b>
network . . . . .	48	<b>Data . . . . .</b>	<b>54</b>	<b>Smart Practices While</b>	
personal organizer . . .	48	<b>European Union Directives</b>		<b>Driving . . . . .</b>	<b>71</b>
security . . . . .	50	<b>Conformance Statement . .</b>		<b>index . . . . .</b>	<b>73</b>
fun & games . . . . .	50	<b>56</b>			
<b>troubleshooting . . . . .</b>	<b>51</b>	<b>Industry Canada Notice to</b>			
check here first . . . . .	51	<b>Users . . . . .</b>	<b>62</b>		
when the backlight is		<b>FCC Notice to Users . . .</b>	<b>62</b>		
turned off, it can seem like		<b>Motorola Limited Warranty</b>			
your phone isn't working .		<b>for the United States and</b>			
51		<b>Canada . . . . .</b>	<b>63</b>		
no display . . . . .	51	<b>Hearing Aid Compatibility</b>			
no backlight on the display		<b>with Mobile Phones . . .</b>	<b>67</b>		
52		<b>Information from the World</b>			
phone doesn't vibrate. 52		<b>Health Organization . . .</b>	<b>68</b>		
messages: "enter special		<b>Product Registration . .</b>	<b>68</b>		
code," "SIM locked -		<b>Export Law Assurances</b>	<b>69</b>		
contact service provider,"		<b>Caring for the Environment</b>			
"subsidy password" . .	52	<b>by Recycling . . . . .</b>	<b>69</b>		


# menu map

## main menu

-  **Contacts**
-  **Call History**
  - Received Calls
  - Dialed Calls
  - Call Times \*
  - Data Times \*
  - Data Volumes \*
-  **Messages**
  - Create
  - Inbox
  - Draft
  - Outbox
  - Quick Notes
  - Voicemail
  - Browser Msgs
  - Info Services
  - MMS Templates
-  **Tools**
  - Calculator
  - MyMenu
  - Alarm Clock
  - Stop Watch
  - Chat
  - Dialing Services
  - Calendar
  - Lantern

-  **Games & Apps**
-  **Internet**
  - Start Browser
  - Web Shortcut
  - Web Session
  - Stored Pages
  - History
  - General Setting

-  **Media**
  - Pictures
  - Sounds

-  **Personalize**
  - Home Screen
  - Main Menu
  - Color Setting
  - Greeting
  - Wallpaper
  - Screen Saver
  - Quick Dial

-  **Settings**  
(see next page)

**Note:** **Chat** and **Quick Dial** depend on your carrier's settings. You may not see these features in your phone.

\* Optional features.

This is the standard main menu layout. **Your phone's menu may be a little different.**

## settings menu



### Ring Style

- Style
- Detail



### Call Forward\*

- Voice Calls
- Cancel All
- Forward Status



### In Call Setup

- In-Call Timer
- My Caller ID \*
- Answer Options
- Call Waiting \*



### Initial Setup

- Time and Date
- 1-Touch Dial
- Display Settings
- Backlight
- Scroll
- Language
- DTMF
- TTY Setup
- Master Reset
- Master Clear
- Format Additional Storage Device
- Status Indicator



### Phone Status

- My Numbers
- Battery Meter



### Headset

- Auto Answer



### Network

- New Network
- Network Setup
- Avail. Networks
- Service Tone
- Call Drop Tone



### Security

- Phone Lock
- Fixed Dial
- Call Barring
- SIM PIN
- New Passwords



### Lantern

- Lantern

**Note:** Service Tone and Band Selection depend on your carrier's settings. You may not see these features in your phone.

\* Optional features

# Use and Care

---

To care for your Motorola phone, please keep it away from:



## liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture.



## dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



## extreme heat or cold

Avoid temperatures below -10°C/14°F or above 45°C/113°F.



## cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



## microwaves

Don't try to dry your phone in a microwave oven.



## the ground

Don't drop your phone.

# essentials

---


**CAUTION:** Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.

## about this guide

This guide shows how to locate a menu feature as follows:

**Find it :**  > **Call History** > **Dialed Calls**

This example shows that, from the home screen, you press  to open the menu, highlight and select **Call History**, then highlight and select **Dialed Calls**.

Press  to scroll to and highlight a menu feature. Press **SELECT** to select the highlighted menu feature.

### symbols



This means a feature depends on the network or subscription and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

## SIM card


Your *Subscriber Identity Module* (SIM) card contains personal information like your phone number and **Contacts** entries.

**Caution:** Do not bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.




## battery

### battery installation



## battery charging

Before you can use your phone, you need to completely charge the battery. New batteries are not fully charged. Plug the travel charger into your phone and an electrical outlet. Your phone displays **Charge Complete** when finished.



**Tip:** You cannot overcharge your battery. It will perform best after you fully charge and discharge it a few times.

New batteries are shipped partially charged. Before you can use your phone, install and charge the battery as described below. Some batteries perform best after several full charge/discharge cycles.

## battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original™ batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.
- When storing your battery, keep it uncharged in a cool, dark, dry place, such as a refrigerator.
- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.



- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.





Contact your local recycling center for proper battery disposal.

**Warning:** Never dispose of batteries in a fire because they may explode.


Before using your phone, read the battery safety information in the “Safety and General Information” section included in the gray-edged pages at the back of this guide.

## turn it on & off


To turn on your phone, press and hold  for 5 seconds. If prompted, enter your SIM card PIN code and/or unlock code.



**Caution:** If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays **SIM Blocked**. Contact your service provider.

To turn off your phone, press and hold  for 5 seconds.


## make a call

Enter a phone number and press  to make a call.

To end the call, press .

## answer a call

When your phone rings and/or vibrates, press

 to answer.



To end the call, press  .

You can also answer or end a call by pressing any key when the **Multi-key** answer option is activated:

**Find it:**  > **Settings** > **In Call Setup**  
> **Answer Options**

## your phone number



To see your number, press  then  while in an idle screen.

# main attractions

---

## multimedia messages

For more message features, see page 42.

### send a multimedia message




A *Multimedia Messaging Service* (MMS) message contains pages with text and media objects (including photos, pictures, animations, or sounds). You can send the multimedia message to other phones with MMS and to email addresses:

**Find it:**  > Messages > Create > Create Message > New Text Msg, New Multimedia Msg or MMS Templates

**Note:** The **MMS templates** can't be downloaded or expanded. You can only use the default templates.

**1** Press keypad keys to enter text on the page. For details about text entry, see page 22.

To insert an **image, sound, or other object** on the page, press **INSERT** or  > **Insert**. Select the file type and the file. Repeat to add/insert another file.

**2** When you finish the message, press **OK**.

**3** Choose one or more people from the **Send** list.

To select a **contacts entry**, highlight the entry, and press **ADD**. Repeat to add other **Contacts** entries.

To **enter** a new number, highlight [**One Time Entry**] and press **SELECT**.

To **enter and store** a new number, highlight [**New Phonebook Entry**] and press **SELECT**. The entry can be saved in your SIM card or to your phone.


- 4 When you finish entering numbers/addresses, press **OK**. Your phone displays the message fields. These fields display when you create a multimedia message.

To enter a **subject** for the message, highlight **Subject** and press **CHANGE**.

To request a **delivery receipt** for the message, highlight **Receipt** and press **CHANGE**, then press **ADD**.


- 5 To send the message, press **SEND**.

To **cancel or save** the message as a **Draft**, press  > **Save to Drafts**.

- 6 To **cancel** the message, go to **Outbox**. If the message is still sending, highlight the message and press  > **Cancel**.

## receive a multimedia message




When you receive a multimedia message, your phone sounds an alert and displays **New Message** with a message indicator, such as .

Press the **READ** key to open the message.

If a multimedia message contains media objects:

- photos, pictures, and animations will display as you read the message.
- sound files will play when its slide bar displays.

# chatting


Select **Chat** from the **Tools** menu to keep in touch with friends. You can save time by inserting a common phrase, such as **In a meeting now** or **Take Care**. Press **NEW** > **Msg:** >  > **INSERT**. See "chat" on page 43.

# basics


---



See page 1 for a basic phone diagram.


## display

The *home screen* displays when you turn on the phone. To dial a number from the home screen, press the number keys and .

**Note:** Your home screen may look different depending on your service provider.




When  is displayed, you can press  to open the menu. Labels at the bottom corners of the display show the current soft key functions. Press the left or right soft key to perform the function indicated by the label. For soft key locations, see page 1.


In the home screen, press  up, down, left, or right to open basic menu features. You can choose to show or hide home screen display icons:



**Find it:**  > Personalize > Home Screen  
> Home Keys > Icons

## status indicators

Status indicators are shown at the top of the home screen:





**1 Signal Strength Indicator** –Vertical bars show the strength of the network connection. You cannot make or receive calls when  displays.


**2 GPRS Indicator** –Shows when your phone is using a high-speed GPRS network connection. Indicators show **PDP context active**  or **packet data available** .



**3 Data Indicator** –Shows connection status.

 = secure packet data transfer

 = unsecure packet data transfer

 = secure application connection

 = unsecure application connection

 = secure *Circuit Switch Data* (CSD) call

 = unsecure CSD call

**4 Roam Indicator** –Shows when your phone is seeking or using a network outside of your home network. Indicator shows ▲.







**5 Active Line Indicator** –Shows to indicate an active call, or to indicate when call forwarding is on.





**6 Message Indicator** –Shows when you receive a new message. Indicators can include:



 = text message     = voicemail message


 = voicemail & text message     = active chat session

**7 Ring Style Indicator** –Shows the ring style setting.

 = loud ring     = vibrate then ring

 = soft ring     = silent


 = vibrate

 = vibrate & ring

**8 Battery Level Indicator** –Vertical bars show the battery charge level. Recharge the battery when your phone shows **Low Battery**.

## status icons

The status icons show the status of incoming calls, messages, and the battery.



### alert/icon

#### **call icon**

Icon rapidly flashes green for incoming calls from a known caller, and slowly flashes green for 30 minutes when there is a missed call from a known caller.

Icon rapidly flashes orange for incoming calls from an unknown caller, and slowly flashes orange for 30 minutes when there is a missed call from an unknown caller.

#### **message icon**

Icon flashes blue for 30 minutes when there is a new text or voice message.


#### **battery icon**


Icon flashes orange when the battery power is low, and is continually lit when the battery is charging.

**Note:** You can turn the Call and Message Icons on and off. Press  > **Settings** > **Initial Setup** > **Status Indicator**.










**Note:** The Battery Icon cannot be turned off.

# menus

From the home screen, press  to enter the main menu.




The following menu icons may be available, depending on your service provider and service subscription options.

menu features	
 <b>Contacts</b>	 <b>Internet</b>
 <b>Call History</b>	 <b>Media</b>
 <b>Messages</b>	 <b>Personalize</b>
 <b>Tools</b>	 <b>Settings</b>
 <b>Games &amp; Apps</b>	

## select a feature option

Some features require you to select an option from a list:




- Press **↑** or **↓** to highlight the option you want.
- In a numbered list, press a number key to highlight an option.
- In an alphabetized list, press a key repeatedly to cycle through the letters and highlight the closest matching option on the list.

- When an option has a list of possible settings, press **←** or **→** to select the setting.
- When an option has a list of possible numeric values, press a number key to set the value.

## text entry

Some features let you enter text:



## choosing a text entry method

Multiple text entry methods make it easy for you to enter names, numbers, and messages. The method you select remains active until you select another method.

Press **#** in any text entry screen to select one of the following entry methods:

- Primary** The primary text entry method (see below to set).
- Numeric** Enter numbers only (see page 42).
- Symbol** Enter symbols only (see page 42).

## set up a text entry mode

To set your **Primary** and **Secondary** text entry modes, press **≡** > **Entry Setup** in a text entry view and select **Primary setup** or **Secondary setup**.

## iTAP™ mode

Press **#** in a text entry screen to switch to iTAP mode. If you don't see **□□** or **□□**, press **≡** > **Entry Setup** to set iTAP mode as your primary or secondary text entry mode.

iTAP mode lets you enter words using one keypress per letter. The iTAP software combines your keypresses into common words and predicts each word as you enter it.

For example, if you press **7 7 6 4**, your phone displays:




- If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining characters.
- Press **[1]** to enter punctuation or other characters.

## tap mode

Press **[#]** in a text entry screen to switch to **TAP** mode. If you do not see **1** or **2**, press **[☰] > Entry Setup** to set **TAP** mode as your **Primary** or **Secondary** text entry mode.

To enter text in **TAP** mode, press a keypad key repeatedly to cycle through the letters and number on the key. Repeat this step to enter each letter.

For example, if you press **[8]** one time, your phone displays:



After 2 seconds, the character is accepted and the cursor moves to the next position.

## numeric mode

In a text entry screen, press **[#]** to switch entry modes until the **12** (numeric) indicator displays.

Press keypad keys to enter the numbers you want. When you finish entering numbers, press **[#]** to switch to another entry mode.

## symbol mode

In a text entry screen, press **#** to switch entry modes until the @ (symbol) indicator displays.

Press keypad keys repeatedly to cycle through its symbols. Highlight the symbol you want, then press **SELECT**.


## volume

You can adjust the earpiece speaker volume while you are talking by pressing **◂** right/up to increase the volume or left/down to decrease the volume. You can also adjust the volume by pressing the side volume keys.

**Tip:** During a call, you can set your phone to mute by pressing **Mute**.

## navigation key

Press the *navigation* key **◂** up, down, left, or right to scroll and highlight options.



## handsfree speaker


You can use your phone's handsfree speaker to make calls without holding the phone to your ear.

During a call, press **SPKR ON** to turn the handsfree speaker on. When your handsfree speaker is on, you can press **SPKR OFF** to turn it off.






**Note:** The handsfree speaker does not work when your phone is connected to a handsfree car kit or headset.

## codes & passwords

Your phone's **unlock code** is originally set to **1234**. The **security code** is originally set to **000000**. If your service provider didn't change these codes, you should change them:

**Find it:**  > Settings > Security > New Passwords

You can also change your **SIM PIN** or call barring passwords.

**If you forget your unlock code:** At the **Enter Unlock Code** prompt, try entering     or the last four digits of your phone number. If that doesn't work, press  and enter your security code instead.

**If you forget your other codes:** If you forget your security code, SIM PIN code, PIN2 code, or call barring password, contact your service provider.

## check battery meter

To check your battery meter:


**Find it:**  > Settings > Phone Status > Battery Meter


# customize

---


## ring style

Your phone rings and/or vibrates to notify you of an incoming call, message, or other event. This ring and/or vibration is called an alert. You can select one of six different alert profiles: **Loud Ring**, **Soft Ring**, **Vibrate**, **Vibrate & Ring**, **Vibrate then Ring**, and **Silent**.

 = Loud

 = Vibrate

 = Soft

 = Silent

 = Vibe then Ring


 = Vibrate & Ring

The ring style profile's indicator displays at the top of your home screen. To choose your profile:

**Find it:**  > Settings > Ring Style > Style  
> *style name*


## change alerts


You can change the alerts for incoming calls and other events. Your changes are saved in the current ring style profile:

**Find it:**  > Settings > Ring Style > Detail  
> *event* > Change > *alert for event*

## time & date

To set the time and date for your phone:

**Find it:**  > Settings > Initial Setup > Time and Date  
> Autoupdate


**Note:** To choose an analog or digital clock for your home screen, press  > **Personalize** > **Home Screen** > **Clock Set**.

## time, date, date format, and autoupdate setup



When you activate the *Autoupdate feature*, your phone's clock will automatically adjust to the correct time zone when you travel from one time zone to another.

**Note:** If your phone's clock does not adjust to the correct time zone, verify that the *Autoupdate feature* is activated. This function depends on your carrier's setting. You may not see this feature in your phone:

**Find it:**  > **Settings** > **Initial Setup** > **Time and Date** > **Autoupdate**

## wallpaper

You can set a picture or animation as a wallpaper (background) image on your home screen:

**Find it:**  > **Personalize** > **Wallpaper**

Select one of the following options:

option	
<b>Set Layout</b>	Select <b>Center</b> to center the image on the display, <b>Tile</b> to repeat the image across the display, <b>Fit-to-Screen</b> to fit the image to the display.
<b>Picture</b>	Select an image for your wallpaper image.

## screen saver

You can set a picture or animation as a screen saver image. The screen saver displays when no activity is detected for a specified time.

**Tip:** This feature helps save your screen but not your battery. To extend battery life, turn off the screen saver:

**Find it:**  > Personalize > Screen Saver

## display appearance


To choose the colors that your phone uses for indicators, highlights, and soft key labels:

**Find it:**  > Personalize > Color Setting

## backlight

To save battery life, the backlight turns off when you are not using your phone. The


backlight turns back on when you press any key. To set how long your phone waits before the backlight turns off:

**Find it:**  > Settings > Initial Setup > Backlight

## answer options

You can use additional, alternative methods to answer an incoming call. To activate or deactivate an answer option:

**Find it:**  > Settings > In Call Setup  
> Answer Options

option	
<b>Multi-key On</b>	Answer by pressing any key or open to answer.
<b>Multi-key Off</b>	Answer by pressing  .
<b>Open to answer</b>	Answer by opening the flip.

## optional handsfree operation

A phone headset enables you to use your phone without using your hands.

**Note:** The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products:

**Find it:**  > **Settings** > **Headset** > **Auto Answer**  
> *mode*


# calls

---


This chapter describes features related to making and answering calls.



## call history


Your phone keeps lists of incoming and outgoing calls, even for calls that did not connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.

**Tip:** Press  from the home screen to see the **Dialed Calls** list:

**Find it:**  > **Call History**

- 1 Press  to scroll to **Received Calls** or **Dialed Calls**.
- 2 Press **SELECT** to select the list.

- 3 Press  to scroll to an entry. A ✓ means the call connected.
- 4 Press  to call the number.
- 5 Press **VIEW** to see call details.

To see the **Dialed Calls** list, press . This menu can include:

option	
<b>Store</b>	Create a <b>Contacts</b> entry with the number in the <b>No.</b> field.
<b>Delete</b>	Delete the entry.
<b>Delete All</b>	Delete all entries in the list.
<b>Hide ID</b>	Hide your caller ID for the next call.
<b>Send Message</b>	Deliver a message.

option	
<b>Add Digits</b>	Add digits after the number.
<b>Attach Number</b>	Attach a number from <b>Contacts</b> or <b>Call History</b> lists.

## redial



- 1 Press to view the **Dialed Calls** list.
- 2 Press to scroll to the entry you want to call.
- 3 Press to redial the number. If you hear a busy signal and see **Call Failed**, **Number Busy**, press to redial the number.

## return a call

Your phone keeps a record of your unanswered calls and displays **X Missed Calls**, where **X** is the number of missed calls.

- 1 Press the **VIEW** key to see the **Received Calls** list.
- 2 Press to select a call to return.
- 3 Press to make the call.

## hold or mute a call

When you are on a call:

Press > **Hold** to put all active calls on hold.

Press > **Mute** to put all active calls on mute.

Press again to turn **Mute** off.

## call waiting



When you're using your phone, you will hear an alert if you receive a second call.

- 1 Press to answer the new call.
- 2 Press **SWITCH** to switch between calls.  
**or**

Press **LINK** to connect the 2 calls.

**or**

Press  > **End Call On Hold** to end the call on hold.

To turn the call waiting feature on or off:

**Find it:**  > **Settings** > **In Call Setup**  
> **Call Waiting**

## caller ID



*Calling line identification* (caller ID) shows the phone number for an incoming call on your external and internal displays.

Your phone shows the caller's name when it's stored in **Contacts**, or **Incoming Call** when caller ID information isn't available.

To show or hide **your phone number** for the next outgoing call or for all calls:


**Find it:**  > **Settings** > **In Call Setup**  
> **My Caller ID**

## emergency calls

Your service provider programs one or more emergency phone numbers (such as 911) that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

**Note:** Emergency numbers vary by country. The preprogrammed emergency number(s) in your phone may not work in all locations. Sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

To call the emergency number at any time:

- 1 Press the keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

## international calls



If your phone service includes international dialing, press and hold **0** to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code, such as +**4 4** for the U.K., +**3 3** for France, etc., and phone number.

## 1-touch dial

To call **Contacts** entries 1 through 9, press and hold the 1-Touch Dial number for one second.

You can set 1-Touch Dial to call the entries in your phone's **Contacts** list, your SIM card's contacts, or your **Fixed Dial** list:

**Find it:**  > **Settings** > **Initial Setup**  
> **1-Touch Dial** > **Phone, SIM, or Fixed Dial**

**Note:** For more information on the Fixed Dial feature, see the Advanced Calling section on page 37.

You can call **Contacts** entries 1 through 9 with the push of a single key. The first nine numbers save to the SIM card correspond to the 1-Touch Dial keys 1 through 9.

Press and hold the 1-Touch Dial number for one second:

**Find it:**  > **Contacts** > highlight a phone entry >  > **Edit** > **Speed No.**

## voicemail



To listen to your messages, you must call your voicemail phone number. Voicemail messages that you receive are stored on the network, not on your phone. Contact your service provider for more details.

## store your voicemail number

**Find it:**  > Messages >  > Voicemail Setup

- 1 Press keypad keys to enter your voicemail number.
- 2 Press **SAVE** to store the number.

## receive voicemail

When you receive a voicemail message, your phone displays **1 New Message** and a new voicemail indicator on the status pane. (Some networks only indicate when you have messages, whether or not they are new.) If users delete all voicemail messages, the voicemail indicator will disappear.

To listen to your voicemail messages:

**Find it:**  > Messages > Voicemail

Your phone may prompt you to store your voicemail phone number. If you do not have a

voicemail number stored, the phone guides you through storing a number.

## inserting special characters into dialing sequences

You can insert special characters, as well as numbers, in a phone number.

option	
<b>p</b> (pause)	Your phone waits until the call connects before it dials the next digit(s) in the series.
<b>w</b> (wait)	Your phone waits until the call connects, then prompts you for confirmation before it dials the next digit(s).





You can add a pause or a wait while your call is dialing. To add a pause before the phone





connects, press and hold **[\*]**. When **p** appears, press it to add a pause. Or, if you are adding a wait, keep holding **[\*]**. When **w** appears, press it to add a wait.






# other features






---

## advanced calling



feature	
<b>conference call</b>	After your first participant is connected, dial the next number, press  and then press the <b>LINK</b> key. 
<b>attach a phone number</b>	Dial an area code or prefix for a <b>Contacts</b> number, press  > <b>Attach Number</b> . 

feature	
<b>speed dial</b>	Speed dial a <b>Contacts</b> entry:   Enter a speed dial number, press  and then  .  <b>Tip:</b> If you forget the speed dial number for a contact's entry, press  > <b>Contacts</b> , highlight the desired entry, and press the <b>VIEW</b> key.

feature	
<b>lantern</b>	 > <b>Settings</b> > <b>Lantern</b> <b>or</b>  > <b>Tools</b> > <b>Lantern</b> <p>This feature makes your LCD screen function as a flashlight. To deactivate it, press any key.</p>
<b>fixed dial</b>	<p>When you turn on fixed dialing, you can call  only numbers stored in the fixed dial list.</p> <p>To turn fixed dialing on or off:</p>  > <b>Settings</b> > <b>Security</b> > <b>Fixed Dial</b> <p>To use the fixed dial list:</p>  > <b>Tools</b> > <b>Dialing Services</b> > <b>Fixed Dial</b>

feature	
<b>quick dial</b>	<p>Dial preprogrammed phone numbers: </p>  > <b>Tools</b> > <b>Dialing Services</b> > <b>Quick Dial</b>
<b>DTMF tones</b>	<p>Set to <b>Long DTMF</b> or <b>Short DTMF</b>:</p>  > <b>Settings</b> > <b>Initial Setup</b> > <b>DTMF</b>
<b>call forwarding</b>	<p>Setup or cancel call forwarding: </p>  > <b>Settings</b> > <b>Call Forward</b>

# contacts

feature	
<b>add new entry</b>	<p>Create a new <b>Contacts</b> entry:</p> <p> &gt; <b>Contacts</b> &gt;  &gt; <b>New</b> &gt; <b>Number</b></p> <p><b>Shortcut:</b> Key in the the number using keypad keys, then press <b>STORE</b>.</p> <p><b>Note:</b> An entry stored on the SIM card is available only from that SIM card.</p>

feature	
<b>add new entry</b>	<p><b>Note:</b> Your phone's memory limit is 100 entries. The SIM card's memory limit depends on your carrier's SIM card type (maximum 250 entries).</p> <p><b>Tip:</b> Some people have more than one phone number. When creating a <b>Contacts</b> entry, select <b>More</b> to store another number for the same <b>Name</b>.</p>

## feature

### download ringtones

You can use this function to send ringtones from one handset to another:

 > **Messages** > **Create** > **Create Message** > **New Multimedia Msg** > **Insert** > **Sound**

Ringtones can be downloaded from the **Web Browser**. When you receive an MMS from another party, you can retrieve a ringtone from that message. You can also send ringtones through MMS.



**Note:** You can download mp3 ringtones via the **Browser** only.

**Note:** Memory limit for ringtone downloads is 1 MB.

## feature



### dial number

Call a number stored in the contacts folder:





 > **Contacts**, highlight the contact entry, press .







**Shortcut:** In **Contacts**, press a keypad key one or more times to jump to entries that begin with the letters on that key. This method can be narrowed by adding more letters, up to a maximum of 12.

### set category for entry

 > **Contacts** > *entry* >  > **Category**









You can classify an entry into the following categories: **All**, **Business**, **Personal**, **General**, **VIPs**, or a category you create.









feature	
<b>set category view</b>	<p> &gt; <b>Contacts</b> &gt; <i>entry</i> &gt;  &gt; <b>Category</b></p> <p>You can view <b>All</b> entries or those in the predefined category such as <b>Business, Personal, General, VIPs</b>, or a category you create.</p>
<b>search a contacts entry</b>	<p>Press a keypad key one or more times to jump to entries that begin with the key's letters. Press a second letter to jump to entries beginning with the two letters you entered. You can enter up to twelve letters:</p> <p> &gt; <b>Contacts</b> &gt;  &gt; <b>Setup</b> &gt; <b>Search Method</b> &gt; <b>Find/Jump to</b></p>






feature	
<b>sort contacts list</b>	<p>Set the order in which entries are listed:</p> <p> &gt; <b>Contacts</b> &gt;  &gt; <b>Setup</b> &gt; <b>Sorting By</b> &gt; <i>sort order</i></p>
<b>copy a contacts entry</b>	<p>Copy a contact entry to the SIM card, or from the SIM card to the phone:</p> <p> &gt; <b>Contacts</b> &gt; highlight the entry &gt;  &gt; <b>Copy</b> &gt; <b>Entries</b> &gt; <b>To</b></p>
<b>copy multiple entries</b>	<p>Copy multiple contact entries between the phone and SIM card:</p> <p> &gt; <b>Contacts</b>, highlight one entry, press  &gt; <b>Copy</b> &gt; <b>Entries</b>, press <b>CHANGE</b>, highlight another entry, press <b>ADD</b>. Repeat as necessary, press <b>DONE</b>.</p>

# messages







For basic multimedia message features, see page 14.

feature	
<b>send text message</b>	 > Messages > Create > Create Message > New Text Msg 
<b>send multimedia message</b>	 > Messages > Create > Create Message > New Multimedia Msg  <b>Note:</b> Only MMS messages 100 KB or less can be sent and received.
<b>send a quick note</b>	 > Messages > Quick Notes 
<b>send a multimedia template</b>	Open a multimedia template with preloaded media:   > Messages > Create > Create Message > MMS Templates




feature	
<b>read new message</b>	Read a new text or multimedia message:  Press the <b>READ</b> key when the <b>New Message</b> notification displays.
<b>read old messages</b>	Read old messages:   > Messages > Inbox Press  to perform various operations on a message.
<b>read sent messages</b>	Read messages that you sent:   > Messages > Outbox Sent messages are saved in the <b>Outbox</b> .
<b>edit old draft</b>	Save the message that you are editing to the Draft folder for later editing:   > Messages > Draft






feature	
<b>browser messages</b>	Read messages received by your browser:  > Messages > Browser Msgs 
<b>sending and receiving vCard</b>	You can send a vCard by sending an MMS with vCard as an attachment:  > Messages > Create > Create Message > New Multimedia Msg or MMS Templates >  > Insert > Attachment > [New Attachment] > vCard  <b>Note:</b> To change editing modes in the wap editor, press  .
<b>info services</b>	Read subscription-based information services messages:  > Messages > Info Services 

## chat






feature	
<b>start chat</b>	 > Tools > Chat  > New Chat 
<b>receive chat request</b>	Press the <b>ACCEPT</b> key or the <b>IGNORE</b> key. 
<b>end chat</b>	During a chat session:  > End Chat 





## web browser (wap 2.0)




feature	
<b>start browser</b>	 > Internet > Start Browser
<b>go to bookmarks</b>	 > Internet > Web Shortcut
<b>web session</b>	 > Internet > Web Session

feature	
<b>go to stored pages</b>	 > Internet > Stored Pages
<b>view/go to previous sites</b>	 > Internet > History
<b>adjust web settings</b>	 > Internet > General Setting
<b>end web browser</b>	Press  in the Internet menu and choose 4. Exit.  or  > OK

## personalizing


feature	
<b>language</b>	Set menu language:  > Settings > Initial Setup > Language
<b>scroll</b>	Set the highlight bar to stop or wrap around in the menu lists:  > Settings > Initial Setup > Scroll
<b>ring volume</b>	 > Settings > Ring Style > <i>style</i> Detail > Ring Volume
<b>keypad volume</b>	 > Settings > Ring Style > <i>style</i> Detail > Key Volume
<b>set the time and date</b>	 > Settings > Initial Setup > Time and Date

feature	
<b>clock view</b>	<p>Display an analog or digital clock in the home screen:</p> <p> &gt; <b>Personalize</b> &gt; <b>Home Screen</b> &gt; <b>Clock Set</b></p>
<b>menu view</b>	<p>Display the main menu as graphic icons or as a text-based list:</p> <p> &gt; <b>Personalize</b> &gt; <b>Main Menu</b> &gt; <b>View</b></p>
<b>main menu</b>	<p>Reorder items in your phone's main menu:</p> <p> &gt; <b>Personalize</b> &gt; <b>Main Menu</b> &gt; <b>Reorder</b></p>
<b>show/hide menu icons</b>	<p>Show or hide menu feature icons in the home screen:</p> <p> &gt; <b>Personalize</b> &gt; <b>Home Screen</b> &gt; <b>Home keys</b> &gt; <b>Icons</b></p>

feature	
<b>change home keys</b>	<p>Change the functions for the soft keys and navigation key in the home screen:</p> <p> &gt; <b>Personalize</b> &gt; <b>Home Screen</b> &gt; <b>Home keys</b></p>
<b>shortcuts</b>	<p>Create a shortcut to a menu item:</p> <p>Highlight the menu item, then press and hold .</p> <p>To use the shortcut:</p> <p>Press , then press the shortcut number.</p>

## feature


**master reset** Reset all options **except** unlock code, security code, and lifetime timer:

 > **Settings** > **Initial Setup**  
> **Master Reset**

**Note:** Before the master reset, you need to input your security code.

## feature


**master clear** To reset all options to their factory settings and clear all user entries (such as downloaded wallpapers, main menu animation, and sounds):

 > **Settings** > **Initial Setup**  
> **Master Clear**

To clear all information, you need to enter the **Security Code** (000000).





**Warning:** This option erases all **information you have entered** (including contact entries) and **content you have downloaded**. Once you erase the information, it cannot be recovered. All options are reset back to their factory settings, **except** for the unlock code, security code, and lifetime timer.

## call times & costs

**Network connection time** is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.




**The amount of network connection time that you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.**

feature	
<b>call times</b>	Display call timers: 
	 > <b>Call History &gt; Call Times</b>



feature	
<b>in-call timer</b>	Display time during a call: 
	 > <b>Settings &gt; In Call Setup &gt; In-Call Timer</b>
<b>data times</b>	Display data times:
	 > <b>Call History &gt; Data Times</b>
<b>data volumes</b>	Display data volumes:
	 > <b>Call History &gt; Data Volumes</b>

## handsfree operation



**Note:** The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

feature	
<b>speaker-phone</b>	Activate a connected external speakerphone during a call:   Press <b>SPKR ON</b> and <b>SPKR OFF</b> to turn the speakerphone on and off.
<b>auto answer</b>	Automatically answer calls when connected to a car kit or headset:    > <b>Settings</b> > <b>Headset</b> > <b>Auto Answer</b>

## network

feature	
<b>network settings</b>	Display network information and adjust network settings:    > <b>Settings</b> > <b>Network</b>



## personal organizer

feature	
<b>set alarm</b>	 > <b>Tools</b> > <b>Alarm Clock</b>
<b>turn off alarm</b>	To turn off the alarm when it displays, press <b>DISABLE</b> .  To set the alarm to ring later, press the <b>SNOOZE</b> key.
<b>calculator</b>	 > <b>Tools</b> > <b>Calculator</b>





feature	
<b>currency converter</b>	<p>☰ &gt; Tools &gt; Calculator</p> <p>☰ &gt; Exchange Rate</p> <p>Enter exchange rate, press the <b>OK</b> key, enter amount, and select ☰ &gt; <b>Convert Currency</b>.</p>
<b>calendar</b>	<p>Use to schedule reminders of important events/errands:</p> <p>☰ &gt; Tools &gt; Calendar</p>

feature	
<b>stop watch</b>	<p>☰ &gt; Tools &gt; Stop Watch</p> <p>Press <b>START</b> to start counting the time, press <b>STOP</b> to stop counting the time, and press <b>RESET</b> to reset the stopwatch.</p> <p><b>Note:</b> After <b>Stop Watch</b> is activated, you can press <b>SNAPSHOT</b> to keep track of elapsed time for later reference. After you stop the <b>Stop Watch</b>, view elapsed time snapshots by scrolling right or left through snapshot 1, 2, 3, etc.</p>

## security

feature	
<b>SIM PIN</b>	Lock or unlock the SIM card:  > <b>Settings</b> > <b>Security</b> > <b>SIM PIN</b> <b>Caution:</b> If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays <b>SIM Blocked</b> .
<b>phone lock</b>	 > <b>Settings</b> > <b>Security</b> > <b>Phone Lock</b> Select to lock the phone right now or enable/disable the <b>Automatic Lock</b> .

## fun & games

feature	
<b>manage sounds</b>	Manage ring tones and music that you have downloaded:  > <b>Media</b> > <b>Sounds</b>
<b>start browser</b>	 > <b>Internet</b> > <b>Start Browser</b> 
<b>start games</b>	 > <b>Games &amp; Apps</b>

# troubleshooting

---

## check here first

If your phone does not seem to work properly, read this page first.

## when the backlight is turned off, it can seem like your phone isn't working

**Question:** My phone does not turn on when I press the keys, but I know the battery is good.

**Answer:** If the backlight set to off, it might appear as if the phone is not working. Check the backlight setting.

**Find it:**  > Settings > Initial Setup  
> Backlight

## no display

**Question:** Why can't I see the display when I use my phone? I know the battery is good.

**Answer:** The backlight may be set to off. Check the backlight setting.

**Find it:**  > Settings > Initial Setup  
> Backlight

## no backlight on the display


**Question:** During phone operation, why don't I see a backlight on the display?

**Answer:** The backlight may be set to off. Check the setting.

**Find it:**  > Settings > Initial Setup  
> Backlight

## phone doesn't vibrate

**Question:** My phone doesn't vibrate when I have an incoming call or message. Why not?

**Answer:** Make sure the volume setting is 0. Press  right or left to adjust the volume to 0.

## messages: "enter special code," "SIM locked - contact service provider," "subsidy password"

**Question:** What do these messages mean?

**Answer:** You might see this message if you have an incorrect SIM card or if you have incorrectly entered your code too many times, depending on your carrier. You will have to enter it correctly. Contact your service provider, if necessary. You might need to replace your SIM card.

# service & repairs

---

If you have questions or need assistance, we're here to help.

Go to [www.motorola.com/consumer/support](http://www.motorola.com/consumer/support), where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

# Specific Absorption Rate Data

---

## This model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.<sup>1</sup> Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR

level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone (850/1800/1900) when tested for use at the ear is 1.40 W/kg, and when worn on the body, as described in this user guide, is 1.03 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).<sup>2</sup>

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>


or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>


1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

# European Union Directives Conformance Statement

---

 Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [www.motorola.com/rtte](http://www.motorola.com/rtte). To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the Web site.



***MOTOROLA***

# Important Safety and Legal Information

# Safety and General Information

---

**This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.\***

## Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

## Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in

---

\* The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2007.

the relevant standards, always follow these instructions and precautions.

## External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

## Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola—or if you hang your mobile device from a lanyard around your neck—keep the mobile

device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: [www.motorola.com](http://www.motorola.com).

## RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

### Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

## Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your health care provider.

## Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue use if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- Do not place a mobile device in the airbag deployment area.

Responsible driving practices can be found in the "Smart Practices While Driving" section in this user's guide and/or at the Motorola Web site: [www.motorola.com/callsmart](http://www.motorola.com/callsmart).

**Note:** The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

## Operational Warnings

Obey all posted signs when using mobile devices in public areas.







### Potentially Explosive Atmospheres


Areas with potentially explosive atmospheres are often but not always posted and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

### Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.
	Do not let your battery, charger, or mobile device get wet.

Symbol	Definition
	Listening at full volume to music or voice through a headset may damage your hearing.

## Batteries and Chargers

**Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see the “Battery Use & Battery Safety” section in this user’s guide.**

## Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

## Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

## Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

## Caution About High Volume Usage



Listening at full volume to music or voice through a headset may damage your hearing.

## Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of

your body. If you continue to have discomfort during or after such use, stop use and see a physician.

## Industry Canada Notice to Users

---

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept

any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

## FCC Notice to Users

---

**The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.**

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Motorola Limited Warranty for the United States and Canada

---

### What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by

consumers in the United States or Canada, which are accompanied by this written warranty:

### Products and Accessories

Products Covered	Length of Coverage
<b>Products and Accessories</b> as defined above, unless otherwise provided for below.	<b>One (1) year</b> from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.

<b>Products Covered</b>	<b>Length of Coverage</b>
<b>Decorative Accessories and Cases.</b> Decorative covers, bezels, PhoneWrap™ covers and cases.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.
<b>Monaural Headsets.</b> Ear buds and boom headsets that transmit mono sound through a wired connection.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.
<b>Consumer and Professional Two-Way Radio Accessories.</b>	<b>Ninety (90) days</b> from the date of purchase by the first consumer purchaser of the product.
<b>Products and Accessories that are Repaired or Replaced.</b>	<b>The balance of the original warranty or for ninety (90) days</b> from the date returned to the consumer, whichever is longer.

#### Exclusions

**Normal Wear and Tear.** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries.** Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

**Abuse & Misuse.** Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

**Use of Non-Motorola Products and Accessories.** Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

**Unauthorized Service or Modification.** Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

**Altered Products.** Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

**Communication Services.** Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

## Software

Products Covered	Length of Coverage
<b>Software.</b> Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	<b>Ninety (90) days</b> from the date of purchase.

## Exclusions

**Software Embodied in Physical Media.** No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

**Software NOT Embodied in Physical Media.** Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.

## Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

## What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

## How to Obtain Warranty Service or Other Information

<b>USA</b>	<b>Phones</b> 1-800-331-6456 <b>Pagers</b> 1-800-548-9954 <b>Two-Way Radios and Messaging Devices</b> 1-800-353-2729
------------	---

<b>Canada</b>	<b>All Products</b> 1-800-461-4575
<b>TTY</b>	1-888-390-6456
For <b>Accessories</b> and <b>Software</b> , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

## What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL

MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

**Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.**

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

# Hearing Aid Compatibility with Mobile Phones

---

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

# Information from the World Health Organization

---

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF

exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int/peh-emf>

## Product Registration

---

Online Product Registration:

[direct.motorola.com/hellomoto/Motosupport/source/registration.asp](http://direct.motorola.com/hellomoto/Motosupport/source/registration.asp)

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

# Export Law Assurances

---

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation

or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

## Caring for the Environment by Recycling

---



This symbol on a Motorola product means the product should not be disposed of with household waste.

### Disposal of your Mobile Device and Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved

national recycling schemes, and further information on Motorola recycling activities can be found at: [www.motorola.com/recycling](http://www.motorola.com/recycling)

### Disposal of your Mobile Device Packaging and User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

# California Perchlorate Label

---

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

“Perchlorate Material – special handling may apply. See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate).”

There is no special handling required by consumers.

## Privacy and Data Security

---

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device’s keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device which updates the device’s security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or

turning it in for recycling. For step-by-step instructions on how to delete all personal information from your device, see the section entitled “master clear” or “delete data” in this user’s guide.

**Note:** For information on backing up your mobile device data before erasing it, go to [www.motorola.com](http://www.motorola.com) and then navigate to the “downloads” section of the consumer Web page for “Motorola Backup” or “Motorola Phone Tools.”

- **Understanding AGPS**—In order to comply with emergency caller location requirements of the FCC, certain Motorola mobile devices incorporate *Assisted Global Positioning System* (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user’s location—for example, to provide

driving directions. Users who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how use of your mobile device may impact your privacy or data security, please contact Motorola at [privacy@motorola.com](mailto:privacy@motorola.com), or contact your service provider.

## Smart Practices While Driving

---

### Drive Safe, Call Smart <sup>SM</sup>

**Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to [www.motorola.com/callsmart](http://www.motorola.com/callsmart) for more information.**

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.

- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.



TM

- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.\*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.\*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.\*

---

\* Wherever wireless phone service is available.

# index

---

- A**
  - accessories 9, 25, 48
  - accessory connector port 1, 3
  - alarm clock 48
  - alarm, set 48
  - alarm, turn off 48
  - alert
    - set 27
    - turn off 27
  - animation 14, 28
  - answer a call 7, 13, 29
  - attach a number 32, 37
- B**
  - backlight 7, 11, 29
  - battery 10
    - extending battery life 11, 29
  - battery life, extending 7, 11
- C**
  - cables 1, 11
  - calculator 6, 48
  - calendar 6, 49
  - call
    - answer 7, 13, 29
    - end 12
    - make 12
    - waiting 32
  - call forwarding 38
  - call history 31
  - call timers 47
  - caller ID 33, 48
  - calls
    - international 34
    - car kit 25, 48
    - center key 1, 3, 25
    - center select key 25
    - chat 6, 43
    - codes 26
    - color style 29
    - conference call 37
    - contacts 31, 32, 37
    - currency converter 49
- D**
  - data call 18
  - data times 47
  - data volumes, tracking 47
  - date
    - set 44
  - dial

fixed 38  
speed 37  
dial a phone number 12  
dialing services 38  
display 9, 17, 29  
    backlight 29  
DTMF tones 38

## **E**

earpiece volume 25  
emergency number 12, 33  
end a call 12  
end key 1, 3, 12  
enter unlock code message  
    26  
export regulations 69  
external display 3

## **F**

fax call 18  
fixed dial 38

frequently asked questions  
    51

## **G**

games 50

## **H**

handsfree speaker 25  
headset 25, 48  
headset jack 1, 3  
hearing aids 67  
home screen 9, 17, 29, 45

## **I**

incoming call message 33  
indicator  
    battery 19  
    message 15, 19  
    ring style 19  
    roam 19  
    signal strength 18

voicemail message 19  
initial setup 27  
international calls 34  
iTAP text entry  
    setup 23  
iTAP text entry mode 23

## **K**

keypad 14, 29, 44

## **L**

language 44  
lock  
    phone 50

## **M**

make a call 12  
master clear 46  
master reset 46  
menu 9, 44, 45  
menu icons 45

message 23, 42  
message indicator 3  
message reminders 49  
missed calls message 32  
MMS 14  
multimedia messages 14  
music 40, 50  
mute a call 25, 32

## **N**

navigation key 1, 3, 25  
network  
    settings 48  
network settings 48  
NITZ 28  
numeric entry mode 24

## **O**

optional accessory 9  
optional feature 9

## **P**

passwords. See codes  
perchlorate label 70  
phone number 13  
picture ID 48  
power key 1, 3, 12

## **Q**

quick dial 38

## **R**

redial 32  
reminders 49  
return a call 32  
ring style indicator 27  
ring style, setting 27  
ring tone 40, 50  
ring volume 44  
ringer volume 44

## **S**

safety information 58  
safety tips 71  
security code 26  
send key 1, 3, 12  
set time and date 44  
setup  
    initial 27  
shortcuts 45  
SIM (Subscriber Identity  
    Module) card 10  
SIM PIN 26  
smart key 3, 45  
soft keys 1, 3, 45  
sounds 50  
speakerphone 25, 48  
speed dial 37  
standby time, increasing 29  
stop watch 49  
store your number 13  
symbol entry mode 25

## T

- tap text entry
  - setup 24
- tap text entry mode 24
- templates
  - MMS 14
- text entry 22
  - setup 23
- text message 23, 42
- time
  - set 44
- time zone, automatic 28
- timers 47
- troubleshooting 51
- turn on/off 12

## U

- unlock
  - phone 26
- unlock code 26

## V

- voicemail 34
- voicemail message indicator
  - 35
- volume 25, 44

## W

- wallpaper 28
- warranty 63
- web browser 43
- web browser, start 50
- WHO information 68

## Y

- your phone number 13



[www.motorola.com](http://www.motorola.com)



6809512A76-A